

# It is highly recommended that this manual be read in its entirety before using this product. Do not use this kit beyond the expiration date.

For Research Purposes Only. Not for use in diagnostic or therapeutic procedures. Purchase does not include or carry the right to resell or transfer this product either as a stand-alone product or as a component of another product. Any use of this product other than the permitted use without the express written authorization of BioLegend is strictly prohibited.

Table of ContentsPag	e
Chapter 1: KIT DESCRIPTION	3
Introduction	3
Principle of the Assay	4
Beads Usage	4
Storage Information	6
Materials Supplied	6
Materials to be Provided by the End-User	8
Precautions	9
Chapter 2: ASSAY PREPARATION 1	.0
Sample Collection and Handling 1	.0
Reagent Preparation 1	.0
Standard Preparation 1	.1
Sample Dilution 1	.2
Chapter 3: ASSAY PROCEDURE 1	.3
Performing the Assay Using a Filter Plate 1	.3
Performing the Assay Using a V-bottom Plate 1	.6
Chapter 4: FLOW CYTOMETER SETUP1	.9
Chapter 5: DATA ACQUISITION AND ANALYSIS	.9
Data Acquisition1	.9
Data Analysis2	20
Chapter 6: ASSAY CHARACTERIZATION	-1
Representative Standard Curve 2	1
Assay Sensitivity 2	1
Cross-Reactivity2	2
Acuracy (Spike Recovery) 2	25
Linearity of Dilution 2	26

Intra-Assay Precision	27
Inter-Assay Precision	28
Biological Samples	29
TROUBLESHOOTING	33
PLATE MAP	37

# Chapter 1: KIT DESCRIPTION

# Introduction

Immune checkpoint molecules are important regulators of immune activation. This regulation is critical to maintaining immune homeostasis, and is driven by a complex interplay of both co-stimulatory and inhibitory signals. These checkpoints are key to preventing autoimmunity in healthy individuals; however, cancer cells often exploit this system by modulating the expression of these molecules in order to suppress anti-tumor responses during host immuno-editing. The ability to accurately quantify expression levels of checkpoint molecules is critical to ongoing biomedical research efforts exploring potential therapeutic interventions to overcome tumor-mediated immune-evasion.

The LEGENDplex<sup>TM</sup> HU Immune Checkpoint Panel 1 (12-plex) is a bead-based multiplex assay panel, using fluorescence-encoded beads suitable for use on various flow cytometers. It allows for simultaneous quantification of 12 key oncology-related immune checkpoint biomarkers such as sCD25 (IL-2Ra), 4-1BB, sCD27, B7.2 (CD86), Free Active TGF- $\beta$ 1, CTLA-4, PD-L1, PD-L2, PD-1, Tim-3, LAG-3, and Galectin-9. This assay panel provides higher detection sensitivity and broader dynamic range than traditional ELISA methods. The panel has been validated for use on cell culture supernatant, serum, and plasma samples.

Catalog No.	Plex Size	Targets	Recommended Sample Type	Recommended Dilution Factor
740866 740867	12-plex	sCD25 (IL-2Ra), 4-1BB, sCD27, B7.2 (CD86), Free Active TGF-β1, CTLA-4, PD-L1, PD-L2, PD-1, Tim-3, LAG-3, Galectin-9	Tissue culture	Varies
740961	10 play	sCD25 (IL-2Ra), 4-1BB, B7.2 (CD86), Free Ac-	Serum, Plasma	2
740962	10-plex	tive TGF-β1, CTLA-4, PD-L1, PD-1, Tim-3, LAG-3, Galectin-9	Tissue culture	Varies
740963	2		Serum, Plasma	100
740964	2-plex	sCD27, PD-L2	Tissue culture	Varies

The LEGENDplex<sup>™</sup> HU Immune Checkpoint Panel 1 is configured as shown below depending on sample types and required dilutions:

The LEGENDplex<sup>™</sup> HU Immune Checkpoint Panel 1 is designed to allow flexible customization within the panel. Please visit www.biolegend.com/legendplex for more information on how to mix and match within the panel.

This assay is for research use only.

## Principle of the Assay

BioLegend's LEGENDplex<sup>™</sup> assays are bead-based immunoassays using the same basic principle as sandwich immunoassays.

Beads are differentiated by size and internal fluorescence intensities. Each bead set is conjugated with a specific antibody on its surface and serves as the capture beads for that particular analyte. When a selected panel of capture beads is mixed and incubated with a sample containing target analytes specific to the capture antibodies, each analyte will bind to its specific capture beads. After washing, a biotinylated detection antibody cocktail is added, and each detection antibody in the cocktail will bind to its specific analyte bound on the capture beads, thus forming capture bead-analyte-detection antibody sandwiches. Streptavidin-phycoerythrin (SA-PE) is subsequently added, which will bind to the biotinylated detection antibodies, providing fluorescent signal intensities in proportion to the amount of bound analytes.

Since the beads are differentiated by size and internal fluorescence intensity on a flow cytometer, analyte-specific populations can be segregated and PE fluorescent signal quantified. The concentration of a particular analyte is determined using a standard curve generated in the same assay.

## Beads Usage

The LEGENDplex<sup>™</sup> bead-based assay system uses two sets of beads. Each set has a unique size that can be identified based on their forward scatter (FSC) and side scatter (SSC) profiles (Beads A and Beads B, Figure 1). Each bead set can be further resolved based on their internal fluorescence intensities. The internal dye can be detected using FL3, FL4, or APC channel, depending on the type of flow cytometer used. The smaller Beads A consists of 6 bead populations and the larger Beads B consists of 7 bead populations (Figure 2-3).

Using 12 bead populations distinguished by size and internal fluorescent dye, the HU Immune Checkpoint Panel 1 allows simultaneous detection of 12 analytes in a single sample. Each analyte is associated with a particular bead set as indicated (Figures 2-3 and Table 1).




Figure 1. Beads Differentiated by Size

Beads A = smaller beads

Beads B = larger beads





Figure 3. Beads B Classification by FL4



For Beads usage in the panel, please refer to Table 1 below:

Target	Bead ID	Immune Check- point Panel 1 - TC (13-plex) Cat No. 740775 or 740776	Immune Check- point Panel 1 - S/P (11-plex) Cat. No. 740883 or 740884	Immune Check- point Panel 1 - S/P (2-plex) Cat. No. 740885 or 740886	Top Standard Concentrations
sCD25 (IL-2Ra)	A4	v	v		
4-1BB	A6	v	v		
sCD27	A7	v		v	The top standard
B7.2 (CD86)	A8	v	v		concentration of each target may vary and may
Free Active TGF-β1	A10	v	V		
CTLA-4	B2	v	V		subject to change
PD-L1	B3	V	V		from lot to lot. Please refer to
PD-L2	B4	v		v	the lot-specific Certificate of
PD-1	B5	V	V		Analysis for this
Tim-3	B6	v	v		information
LAG-3	B7	V	V		
Galectin-9	B9	V	V		

Table 1. Panel Targets and Bead ID

\*Bead ID is used to associate a bead population to a particular analyte in the LEGENDplex<sup>™</sup> Data Analysis Software. The association of analyte and bead ID will be defined during the gating step of the data analysis.

When entering analyte and bead ID infomation during the gating step, always enter in the sequential order of the bead ID (e.g, A4, A5, A6...B2, B3, B4...). Please refer to the LEGENDplex<sup>™</sup> Data Analysis Software User Guide and Online Help for details (www.biolegend.com/legendplex).

### Storage Information

Recommended storage for all original kit components is between 2°C and 8°C. DO NOT FREEZE Beads, Detection Antibodies or SA-PE.

- Once the standards have been reconstituted, immediately transfer contents into polypropylene vials. DO NOT STORE RECONSTITUTED STAN-DARDS IN GLASS VIALS.
- Upon reconstitution, leftover standard should be stored at ≤-70°C for use within one month. Avoid multiple (>2) freeze-thaw cycles. Discard any leftover diluted standards.

# Materials Supplied

The LEGENDplex<sup>™</sup> kit contains reagents for 100 tests, listed in the table below. When assayed in duplicate, this is enough for an 8-point standard curve and 40 samples.

For the Mix and Match Subpanels, individual beads are provided at 13X concentration. The Buffer Set contains Setup Beads, all Buffers, Plate Sealers, Matrix, SA-PE and Data Analysis Software Dongle. A manual is also provided for each Mix and Match subpanel.

Kit Components	Quantity	Volume	Cat. #
Capture Beads* (see tables below for more information)	varies	varies	varies
LEGENDplex™ HU Immune Check- point Panel 1 Detection Antibodies	1 bottle	3.5 mL	740868
LEGENDplex <sup>™</sup> HU Immune Check- point Panel 1 Standard	1 vial	lyophi- lized	740869
LEGENDplex™ Buffer Set M	1		740981
Filter Plate** or V-bottom Plate***	1 Plate		740377**or 740379***
HU Immune Checkpoint Panel 1 Mix and Match Subpanel Manual	1		750000505

\*\* For assay with filter plate. \*\*\* For assay with V-bottom plate.

Bead Name	Quantity	Volume	Cat. #
LEGENDplex <sup>™</sup> Human sCD25 (IL-2Ra) Capture Bead A4, 13X	1 vial	270 μL	740870
LEGENDplex <sup>™</sup> Human 4-1BB Capture Bead A6, 13X	1 vial	270 μL	740872
LEGENDplex <sup>™</sup> Human sCD27 Capture Bead A7, 13X	1 vial	270 μL	740873
LEGENDplex <sup>™</sup> Human B7.2 (CD86) Capture Bead A8, 13X	1 vial	270 μL	740874
LEGENDplex <sup>™</sup> Human Free Active TGF-β1 Capture Bead A10, 13X	1 vial	270 μL	740875
LEGENDplex <sup>™</sup> Human CTLA-4 Capture Bead B2, 13X	1 vial	270 μL	740876
LEGENDplex <sup>™</sup> Human PD-L1 Capture Bead B3, 13X	1 vial	270 μL	740877
LEGENDplex <sup>™</sup> Human PD-L2 Capture Bead B4, 13X	1 vial	270 μL	740878
LEGENDplex <sup>™</sup> Human PD-1 Capture Bead B5, 13X	1 vial	270 μL	740879
LEGENDplex <sup>™</sup> Human Tim-3 Capture Bead B6, 13X	1 vial	270 μL	740880
LEGENDplex <sup>™</sup> Human LAG-3 Capture Bead B7, 13X	1 vial	270 μL	740881
LEGENDplex™ Human Galectin-9 Capture Bead B9, 13X	1 vial	270 μL	740882

Capture beads for Mix and Match Subpanels\*:

\* Please refer to Beads ID and Panel-Specific Target Selection table (Table 1), to see which capture beads are included in each panel.

## LEGENDplex<sup>™</sup> Buffer Set M (Cat#: 740981)

Components	Quantity	Volume	Part #
Setup Beads 1: FITC Beads	1 vial	1 mL	77840
Setup Beads 2: PE Beads	1 vial	1 mL	77842
Setup Beads 3: Raw Beads	1 vial	2 mL	77844
LEGENDplex <sup>™</sup> SA-PE	1 bottle	3.5 mL	77743
LEGENDplex <sup>™</sup> Matrix A1, Lyophilized	1 vial	lyophilized	750000601
LEGENDplex <sup>™</sup> Assay Buffer	1 bottle	25 mL	77562
LEGENDplex <sup>™</sup> Wash Buffer, 20X	1 bottle	25 mL	77564
Data Analysis Software Dongle	1		21217
Plate Sealers	4 sheets		78101

No plate is included in Buffer Set M. Plate need to be ordered separately. Please order the correct type of plate based on the preferred assay protocol (Cat# 740377 or 740378 for Filter Plate and Cat# 740379 for V-bottom Plate)

## Materials to be Provided by the End-User

• A flow cytometer equipped with two lasers (e.g., a 488 nm blue laser or 532 nm green laser and a 633-635 nm red laser) capable of distinguishing 575 nm and 660 nm or a flow cytometer equipped with one laser (e.g., 488 nm blue laser) capable of distinguishing 575 nm and 670 nm.

Flow Cytometer	Reporter Channel	Reporter Channel Emission	Beads Classification Channel	Classification Channel Emission	Compensation needed?
BD FACSCalibur™	FL2	575 nm	FL4	660 nm	No*
BD Accuri™C6	FL2	585 nm	FL4	675 nm	No*
BD FACSCanto <sup>™</sup> , BD FACSCanto <sup>™</sup> II	PE	575 nm	APC	660 nm	No*
BD <sup>™</sup> LSR, LSR II BD LSRFortessa <sup>™</sup>	PE	575 nm	APC	660 nm	No*
Gallios™	PE	575 nm	APC	660 nm	No*
CytoFLEX	PE	585 nm	APC	660 nm	No*
NovoCyte	PE	572 nm	APC	660 nm	No*
Attune™ NxT	PE	574 nm	APC	670 nm	No*

#### Partial list of compatible flow cytometers:

\*Compensation is not required for the specified flow cytometers when set up properly.

For setting up various flow cytometers, please visit: **www.biolegend.com/ legendplex** and click on the **Instrument Setup** tab.

- Multichannel pipettes capable of dispensing 5  $\mu$ L to 200  $\mu$ L
- Reagent reservoirs for multichannel pipette
- Polypropylene microfuge tubes (1.5 mL)
- Laboratory vortex mixer
- Sonicator bath (e.g., Branson Ultrasonic Cleaner model #B200, or equivalent)
- Aluminum foil
- Absorbent pads or paper towels
- Plate shaker (e.g., Lab-Line Instruments model #4625, or equivalent)
- Tabletop centrifuges (e.g., Eppendorf centrifuge 5415 C, or equivalent)
- 1.1 mL polypropylene micro FACS tubes, in 96-tube rack (e.g., National Scientific Supply Co, catalog # TN0946-01R, or equivalent).

### If the assay is performed in a filter plate (recommended);

- A vacuum filtration unit (Millipore MultiScreen <sup>®</sup> HTS Vacuum Manifold, cat # MSVMHTS00 or equivalent). Instructions on how to use the vacuum manifold can be found at the supplier's website.
- A vacuum source (mini vacuum pump or line vacuum, e.g., Millipore Vacuum Pump, catalog # WP6111560, or equivalent)
- If needed, additional Filter plate can be ordered from BioLegend (Cat# 740377 or 740378)

### If the assay is performed in a V-bottom plate (optional);

- Centrifuge with a swinging bucket adaptor for microtiter plates (e.g., Beckman Coulter Allegra<sup>™</sup> 6R Centrifuge with MICROPLUS CARRIER adaptor for GH3.8 and JS4.3 Rotors).
- If needed, additional V-bottom plate can be ordered from BioLegend (Cat# 740379)

### **Precautions**

- All blood components and biological materials should be handled as potentially hazardous. Follow universal precautions as established by the Center for Disease Control and Prevention and by the Occupational Safety and Health Administration when handling and disposing of infectious agents.
- Sodium azide has been added to some reagents as a preservative. Although the concentrations are low, sodium azide may react with lead and copper plumbing to form highly explosive metal azides. On disposal, flush with a large volume of water to prevent azide build-up.
- Matrix A1 for LEGENDplex<sup>™</sup> kits contains components of animal origin and should be handled as potentially hazardous. Do not mix or substitute reagents from different kits or lots. Reagents from different manufacturers should not be used with this kit.
- Do not use this kit beyond its expiration date.
- SA-PE and beads are light-sensitive. Minimize light exposure.

# Chapter 2: ASSAY PREPARATION

## Sample Collection and Handling

#### Preparation of Serum Samples:

- Allow the blood to clot for at least 30 minutes and centrifuge for 20 minutes at 1,000 x g.
- Remove serum and assay immediately or aliquot and store samples at <-20°C. Avoid multiple (>2) freeze/thaw cycles.
- When using frozen samples, it is recommended that samples are thawed completely, mixed and centrifuged to remove particulates prior to use.

#### Preparation of Plasma Samples:

- Plasma collection using an anti-coagulant (e.g. EDTA, Heparin, Citrate) is recommended. Centrifuge for 20 minutes at 1,000 x g within 30 minutes of blood collection.
- Remove plasma and assay immediately, or aliquot and store samples at <-20°C. Avoid multiple (>2) freeze/thaw cycles.
- When using frozen samples, it is recommended that samples are thawed completely, mixed well and centrifuged to remove particulates.

#### Preparation of Tissue Culture Supernatant:

Centrifuge the sample to remove debris and assay immediately. If not possible, aliquot and store samples at ≤-20°C. Avoid multiple (>2) freeze/thaw cycles.

### **Reagent Preparation**

#### **Preparation of Antibody-Immobilized Beads**

The individual beads (13X) should be diluted to 1X final concentration with Assay Buffer prior to use.

- 1. Sonicate the beads vials for 1 minute in a sonicator bath and then vortex for 30 seconds to completely resuspend the beads.
- 2. Calculate the amount of diluted beads needed for the assay. Prepare extra to compensate for pipetting loss. Each reaction needs 25  $\mu$ L of diluted beads. For 50 reactions, prepare 1.5 mL of mixed beads. For 100 reactions, prepare 3 mL of mixed beads.
- 3. To make 1.5 mL of 10-plex 1X diluted beads, transfer 115  $\mu$ L of each of the 10 individual beads (13X) to a fresh tube (total bead volume = 1150  $\mu$ L) and add 350  $\mu$ L of Assay Buffer to make the final volume of 1.5 mL.

### Preparation of Wash Buffer

- Bring the 20X Wash Buffer to room temperature and mix to bring all salts into solution.
- Dilute 25 mL of 20X Wash Buffer with 475 mL deionized water. Store unused portions between 2°C and 8°C for up to one month.

### Preparation of Matrix A1 (for Serum or Plasma Samples Only)

 Add 5.0 mL LEGENDplex<sup>™</sup> Assay Buffer to the bottle containing lyophilized Matrix A1. Allow at least 15 minutes for complete reconstitution. Vortex to mix well. Leftover reconstituted Matrix A1 should be stored at ≤-70°C for up to one month.

# Standard Preparation

- 1. Prior to use, reconstitute the lyophilized HU Immune Checkpoint Panel 1 Standard Cocktail, with 250  $\mu L$  of Assay Buffer.
- 2. Mix and allow the vial to sit at room temperature for 15 minutes, and then transfer the standard to an appropriately labeled polypropylene microfuge tube. This will be used as the top standard C7.

Note: The top standard concentrations of analytes in this panel was set at various concentrations, but may be subject to change from lot to lot (see lot-specific Certificate of Analysis provided with kit box for details).

- 3. Label 6 polypropylene microfuge tubes as C6, C5, C4, C3, C2 and C1, respectively.
- 4. Add 75  $\mu$ L of Assay Buffer to each of the six tubes. Prepare 1:4 dilution of the top standard by transferring 25  $\mu$ L of the top standard C7 to the C6 tube and mix well. This will be the C6 standard.
- 5. In the same manner, perform serial 1:4 dilutions to obtain C5, C4, C3, C2 and C1 standards (see the table below using the top standard at 10,000 pg/mL as an example). Assay Buffer will be used as the 0 pg/mL standard (C0).

Tube/Standard ID	Serial Dilution	Assay Buffer to add (μL)	Standard to add	Final Conc. (pg/mL)
C7				10,000
C6	1:4	75	25 μL of C7	2,500
C5	1:16	75	25 µL of C6	625
C4	1:64	75	25 μL of C5	156.25
C3	1:256	75	25 µL of C4	39.06
C2	1:1024	75	25 µL of C3	9.76

C1	1:4096	75	25 μL of C2	2.44
CO		75		0

# Sample Dilution

For cell culture supernatant samples, the levels of analyte can vary greatly from sample to sample. While the samples can be tested without dilutions, a preliminary experiment may be required to determine the appropriate dilution factor. If sample dilution is desired, dilution should be done with corresponding fresh cell culture medium or Assay Buffer to ensure accurate measurement.

For serum and plasma samples, follow panel specific dilution recommendations below.

### • For HU Immune Checkpoint Panel 1 - TC (12-plex);

Tissue culture samples are the recommended sample type. Follow the cell culture supernatant dilution guidelines mentioned above.

### • For HU Immune Checkpoint Panel 1 - S/P (10-plex);

Serum or plasma samples must be diluted 2-fold with Assay Buffer as described in the table below.

Sample	Dilution (1:2)	Final dilution fold
Serum, Plasma	50 μL + 50 μL Assay Buffer	2

If further sample dilution is desired, dilution should be done with Matrix A1 to ensure accurate measurement.

### • For HU Immune Checkpoint Panel 1 - S/P (2-plex);

Serum or plasma samples must be diluted 100-fold with Assay Buffer as described in the table below.

Sample	ple 1st Dilution 2nd Dilution (1:10) (1:10)		Final dilution fold
Serum,	5 μL + 45 μL	10 μL + 90 μL	100
Plasma	Assay Buffer	Assay Buffer	

If further sample dilution is desired, dilution should be done with Assay Buffer to ensure accurate measurement.

# Chapter 3: ASSAY PROCEDURE

The LEGENDplex<sup>™</sup> assay can be performed in a filter plate, or in a V-bottom plate.

- The in-filter plate assay procedure is recommended due to its good sample to sample consistency, assay robustness and ease of handling. This procedure requires a vacuum filtration unit for washing (see Materials to be Provided by the End-User, page 8). If you have performed bead-based multiplex assays before, your lab may already have the vacuum filtration unit set up.
- If the in-filter plate assay procedure is not possible or if you prefer, the assay can be performed in a V-bottom plate.

# Performing the Assay Using a Filter Plate

- Allow all reagents to warm to room temperature (20-25°C) before use.
- Set the filter plate on an inverted plate cover at all times during assay setup and incubation steps, so that the bottom of the plate does not touch any surface. Touching a surface may cause leakage.
- Keep the plate upright during the entire assay procedure, including the washing steps, to avoid losing beads.
- The plate should be placed in the dark or wrapped with aluminum foil for all incubation steps.
- Standards and samples should be run in duplicate and arranged on the plate in a vertical configuration convenient for data acquisition and analysis (as shown in attached PLATE MAP, page 37). Be sure to load standards in the first two columns. If an automation device is used for reading, the orientation and reading sequence should be carefully planned.
- Pre-wet the plate by adding 100 µL of LEGENDplex<sup>™</sup> 1X Wash Buffer to each well and let it sit for 1 minute at room temperature. To remove the excess volume, place the plate on the vacuum manifold and apply vacuum. Do not exceed 10" Hg of vacuum. Vacuum until wells are drained (5-10 seconds). Blot excess Wash Buffer from the bottom of the plate by pressing the plate on a stack of clean paper towels. Place the plate on top of the inverted plate cover.

For measuring cell culture supernatant samples in 12-plex, 10-plex, ad 2-plex; and serum or plasma samples in 2-plex, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Matrix A1	Standard	Sample*
Standard Wells	25 μL		25 μL	
Sample wells	25 μL			25 μL

For measuring serum or plasma samples in 10-plex, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Matrix A1	Standard	Sample*
Standard Wells		25 μL	25 μL	
Sample wells	25 μL			25 μL


#### \*See Sample Dilution

- 2. Vortex mixed beads bottle for 30 seconds. Add 25  $\mu$ L of mixed beads to each well. The volume should be 75  $\mu$ L in each well after beads addition. (Note: During addition of the beads, shake mixed beads bottle intermittently to avoid bead settling).
- 3. Seal the plate with a plate sealer. To avoid plate leaking, do not apply positive pressure to the sealer when sealing the plate. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker, secure it and shake at approximate 500 rpm for 2 hours at room temperature.
- 4. Do not invert the plate! Place the plate on the vacuum manifold and apply vacuum as before in Step 1. Add 200 μL of 1X Wash Buffer to each well. Remove Wash Buffer by vacuum filtration. Blot excess Wash Buffer from the bottom of the plate with an absorbent pad or paper towels. Repeat this washing step once more.
- 5. Add 25  $\mu$ L of Detection Antibodies to each well.
- 6. Seal the plate with a fresh plate sealer. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker and shake at approximately 500 rpm for 1 hour at room temperature.
- 7. Do not vacuum! Add 25  $\mu$ L of SA-PE to each well directly.
- 8. Seal the plate with a fresh plate sealer. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker and shake at approximate 500 rpm for 30 minutes at room temperature.
- 9. Repeat step 4 above.
- 10. Add 150  $\mu\text{L}$  of 1X Wash Buffer to each well. Resuspend the beads on a plate shaker for 1 minute.

11. Read samples on a flow cytometer, preferably within the same day of the assay (Note: Prolonged sample storage can lead to reduced signal).

If the flow cytometer is equipped with an autosampler, read the plate directly using the autosampler. Please be sure to program the autosampler to resuspend beads in the well immediately before taking samples. The probe height may need to be adjusted when using an autosampler.

If an autosampler is not available, the samples can be transferred from the filter plate to micro FACS (or FACS) tubes and read manually.



# biolegend.com

# Performing the Assay Using a V-bottom Plate

- Allow all reagents to warm to room temperature (20-25°C) before use.
- Keep the plate upright during the entire assay procedure, including the washing steps, to avoid losing beads.
- The plate should be placed in the dark or wrapped with aluminum foil for all incubation steps.
- Standards and samples should be run in duplicate and arranged on the plate in a vertical configuration convenient for data acquisition and analysis (as shown in attached PLATE MAP, page 37). Be sure to load standards in the first two columns. If an automation device is used for reading, the orientation and reading sequence should be carefully planned.
- For measuring cell culture supernatant samples in 12-plex, 10-plex, ad 2-plex; and serum or plasma samples in 2-plex, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Matrix A1	Standard	Sample*
Standard Wells	25 μL		25 μL	
Sample wells	25 μL			25 μL

For measuring serum or plasma samples in 10-plex, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Matrix A1	Standard	Sample*
Standard Wells		25 μL	25 μL	
Sample wells	25 μL			25 μL

#### \*See Sample Dilution

- 2. Vortex mixed beads for 30 seconds. Add 25  $\mu$ L of mixed beads to each well. The total volume should be 75  $\mu$ L in each well after beads addition. (Note: During beads addition, shake mixed beads bottle intermittently to avoid bead settling).
- 3. Seal the plate with a plate sealer. Cover the entire plate with aluminum foil to protect the plate from light. Shake at 800 rpm on a plate shaker for 2 hours at room temperature (Depending on the shaker, the speed may need to be adjusted. The optimal speed is one that is high enough to keep beads in suspension during incubation, but not too high so it causes spill from the wells).
- 4. Centrifuge the plate at 1050 rpm (~250 g) for 5 minutes, using a swinging bucket rotor (G.H 3.8) with microplate adaptor (Please refer to **Materials to**
- 16 **be Provided by the End-User, page 8).** Do not use excessive centrifugation Tel: 858-768-5800

speed as it may make it harder to resuspend beads in later steps. Make sure that the timer of the centrifuge works properly and standby to make sure the centrifuge reaches preset speed.

5. Immediately after centrifugation, dump the supernatant into a sink by quickly inverting and flicking the plate in one continuous and forceful motion. Do not worry about losing beads even if the pellet is not visible. The beads will stay in the tip of the well nicely. Blot the plate on a stack of clean paper towel and drain the remaining liquid from the well as much as possible. Be careful not to disturb the bead pellet.


Alternatively, removal of the supernatant may be completed using a multichannel pipette set at 75  $\mu$ L. Try to remove as much liquid as possible without removing any beads. Be sure to change pipette tips between each row or column.

- 6. Wash the plate by dispensing 200  $\mu$ L of 1X Wash Buffer into each well and incubate for one minute. Repeat step 4 and 5 above. A second wash is optional , but may help reduce background.
- 7. Add 25  $\mu$ L of Detection Antibodies to each well.
- 8. Seal the plate with a new plate sealer. Cover the entire plate with aluminum foil to protect the plate from light. Shake at 800 rpm on a plate shaker for 1 hour at room temperature.
- 9. Do not wash the plate! Add 25 µL of SA-PE to each well directly.
- 10. Seal the plate with a new plate sealer. Wrap the entire plate with aluminum foil and shake the plate on a plate shaker at approximate 800 rpm for 30 minutes at room temperature.
- 11. Repeat step 4 and 5.
- 12. Wash the plate by dispensing 200  $\mu$ L of 1X Wash Buffer into each well and incubate for one minute. Repeat step 4 and 5 above. This washing step is optional but it helps to reduce the background.
- 13. Add 150  $\mu\text{L}$  of 1X Wash Buffer to each well. Resuspend the beads by pipetting.
- 14. Read samples on a flow cytometer, preferably within the same day of the assay (Note: Prolonged sample storage can lead to reduced signal).

If the flow cytometer is equipped with an autosampler, the samples can be read directly. Please be sure to program the autosampler to resuspend beads in the well immediately before taking samples. The probe height may need to be adjusted when using an autosampler.

If an autosampler is not available, the samples can be transferred from the plate to micro FACS (or FACS) tubes and read manually.

#### Assay Procedure Summary for V-bottom Plate



# Chapter 4: FLOW CYTOMETER SETUP

In order to generate reliable data, the flow cytometer must be set up properly before data acquisition.

The setup instructions have been removed from this manual and uploaded onto our website to save paper.

To access the setup instructions, please visit: **www.biolegend.com/legendplex** and click on the **Instrument Setup** tab.

# Chapter 5: DATA ACQUISITION AND ANALYSIS

# Data Acquisition

- 1. Before reading samples, make sure that the flow cytometer is set up properly.
- 2. Create a new template or open an existing template (for details on how to create a cytometer-specific template, please refer to the Flow Cytometer Setup Guide).
- 3. Vortex each sample for 5 seconds before analysis.
- 4. Set the flow rate to low. Set the number of beads to be acquired to about 300 per analyte. Do not set to acquire total events as samples may contain large amounts of debris. Instead, create a large gate to include both Beads A and Beads B (gate A+B) and set to acquire the number of events in gate A + B. This will exlude majority of the debris.

Note: Do not acquire too few or too many beads. Too few beads acquired may result in high CVs and too many beads acquired may result in slow data analysis later.

5. Read samples.

When reading samples, set the flow cytometer to setup mode first and wait until bead population is stabilized before recording or switching to acquisition mode.

To simplify data analysis using the LEGENDplex<sup>™</sup> Data Analysis Software, read samples in the same order as shown on the PLATE MAP attached at the end of the manual. For an in-plate assay, read column by column (A1, B1, C1...A2, B2, C2...).

When naming data files, try to use simple names with a consecutive numbering for easy data analysis (e.g. for standards, C0.001, C0.002, C1.003, C1.004, C2.005, C2.006, C3.007, C3.008, ... C7.015, C7.016; for samples, S1.017, S1.018, S2.019, S2.020, S3.021, S3.022...)

Store all FCS files in the same folder for each assay. If running multiple assays, create a separate folder for each assay.

6. Proceed to data analysis using LEGENDplex<sup>™</sup> Data Analysis Software when data acquisition is completed.


# Data Analysis

- The FCS file generated on a flow cytometer should be analyzed using BioLegend's LEGENDplex<sup>™</sup> Data Analysis Software. The LEGENDplex<sup>™</sup> Data Analysis Software can be downloaded for free here: www.biolegend.com/ legendplex.
- For PC users, install the software on a PC running Windows 7 or Windows 8 and use it in conjunction with the Data Analysis Software Dongle included in this kit. The dongle has a license key stored in it and is needed to run the software. To use the dongle, simply plug it in the USB port of the computer on which the data analysis software is installed, prior to launching the software.
- For Mac users, install on a Mac running Mac OS X version 10.7 (Lion) or later and you will be promoted to request a software license key after the software installation.
- Follow the LEGENDplex<sup>™</sup> Data Analysis Software User Guide and Online Help to use the software (www.bioLegend.com/legendplex; or press F1 for online help at any step of the data analysis).

# Chapter 6: ASSAY CHARACTERIZATION

# **Representative Standard Curve**

This standard curve was generated using the LEGENDplex<sup>™</sup> HU Immune Checkpoint Panel 1 for demonstration purposes only. A standard curve must be run with each assay.



# Assay Sensitivity

The minimum detectable concentration (MDC) is the theoretical limit of detection calculated using the LEGENDplex<sup>™</sup> Data Analysis Software by applying a 5-parameter curve fitting algorithm.

Analyte	Sensitivity in Serum (pg/mL) (N=12)		Sensitivity in Cell Culture Medium (pg/mL) (N=13)	
	MDC	STDEV	MDC	STDEV
Human sCD25 (IL-2Ra)	4.47	3.68	3.86	2.75
Human 4-1BB	2.59	1.21	3.45	2.28
Human sCD27	15.03	9.99	17.21	11.49
Human B7.2 (CD86)	1.63	0.80	1.90	1.06
Human Free Active TGF-β1	2.38	1.83	3.76	4.70
Human CTLA-4	0.30	0.16	0.37	0.26
Human PD-L1	1.03	0.37	1.09	0.52

Human PD-L2	0.47	0.29	0.43	0.34
Human PD-1	0.92	0.27	1.00	0.58
Human Tim-3	4.73	1.36	4.98	2.80
Human LAG-3	29.28	19.47	29.14	14.90
Human Galectin-9	41.20	17.97	63.37	17.92

## **Cross-Reactivity**

Crossreactivity was tested in the panel using the LEGENDplex<sup>™</sup> HU Immune Checkpoint Panel 1. The following recombinant proteins were tested at respective concentrations. No or negligible cross-reactivity was found for all the tested analytes.

Recombinant Protein	Species Reactivity	Concentration Tested (ng/mL)
4-1BB	Human	500
Angiopoietin-2	Human	50
B7.2 (CD86)	Human	200
CTLA-4	Human	50
CX3CL1 (Fractalkine)	Human	400
EGF	Human	10
ENA-78 (CXCL5)	Human	10
Eotaxin (CCL11)	Human	10
EPO	Human	50
Fas	Human	50
FasL	Human	10
FGF-basic	Human	50
FLT3-L	Human	20
Free Active TGF-β1	Human	200
Galectin-9	Human	4000
G-CSF	Human	50
GM-CSF	Human	10
GM-CSF	Human	50
Granulysin	Human	50
Granzyme A	Human	10

LEGENDplex <sup>™</sup> HL	J Immune Checkpoint Pane	el 1 Mix and Match Subpanel
----------------------------	--------------------------	-----------------------------

Granzyme B	Human	50
GROα (CXCL1)	Human	10
HGF	Human	50
IFN-α	Human	10
IFN-γ	Human	10
IL-10	Human	10
IL-11	Human	50
IL-11	Human	20
IL-12(p40)	Human	50
IL-12(p70)	Human	10
IL-13	Human	10
IL-15	Human	50
IL-15	Human	50
IL-17A	Human	5
IL-17F	Human	10
IL-18	Human	10
IL-1α	Human	10
IL-1β	Human	10
IL-2	Human	10
IL-21	Human	2.5
IL-22	Human	10
IL-23	Human	10
IL-27	Human	10
IL-3	Human	10
IL-33	Human	50
IL-34	Human	100
IL-4	Human	10
IL-5	Human	10
IL-6	Human	10
IL-7	Human	10
IL-8 (CXCL8)	Human	10
IL-9	Human	10
IP-10 (CXCL10)	Human	10

I-TAC (CXCL11)	Human	10
LAG-3	Human	2000
LIF	Human	200
MCP-1 (CCL2)	Human	10
M-CSF	Human	10
M-CSF	Human	10
MIG (CXCL9)	Human	10
MIP-1α (CCL3)	Human	10
MIP-1β (CCL4)	Human	10
MIP-3α (CCL20)	Human	10
PAI-1	Human	200
PD-1	Human	100
PDGF-AA	Human	50
PDGF-BB	Human	50
PD-L1	Human	100
PD-L2	Human	50
Perforin	Human	10
PTX3	Human	100
Rantes (CCL5)	Human	10
sCD130 (gp130)	Human	400
sCD25 (IL-2Ra)	Human	500
sCD27	Human	2000
sCD40L	Human	50
SCF	Human	10
SCF	Human	10
SDF-1β	Mouse	250
sRAGE	Human	100
sST2	Human	400
sTNF-RI (sCD120a)	Human	10
sTNF-RII (sCD120b)	Human	20
sTREM-1	Human	50
TARC (CCL17)	Human	10
TGF-α	Human	50

Tim-3	Human	500
TNF-α	Human	10
TSLP	Human	10
VEGF121	Human	50

# Accuracy (Spike Recovery)

For spike recovery in serum and plasma, target proteins with known concentrations were spiked into human serum and plasma at three different levels within the assay range. The spiked samples were then assayed, and the measured concentrations were compared with the expected values.

Analyte	% of Recovery in Serum (N = 10)	% of Recovery in Plasma (N = 10)
Human sCD25 (IL-2Ra)	84%	76%
Human 4-1BB	93%	90%
Human sCD27	106%	121%
Human B7.2 (CD86)	84%	74%
Human Free Active TGF-β1*	86%	28%
Human CTLA-4*	98%	40%
Human PD-L1	126%	114%
Human PD-L2	103%	115%
Human PD-1	97%	104%
Human Tim-3	119%	150%
Human LAG-3	98%	82%
Human Galectin-9	85%	64%

\*Note: Recovery in plasma is poor for some anlaytes. Serum is the preferred sample type.

## Linearity of Dilution

For testing linearity of dilution, serum and plasma samples were first diluted two-fold with Assay Buffer and spiked with target proteins at known concentrations. The spiked samples were then serially diluted 1:2, 1:4, 1:8 with Matrix A1 and assayed. For human sCD27 and human PD-L2, serum and plasma samples were first diluted 100-fold with Assay Buffer and then serially diluted 1:2, 1:4, 1:8 with Assay Buffer and assayed. The measured concentrations of serially diluted samples were then compared with that of the two-fold diluted samples and neat samples, respectively.

Analyte	Linearity of Dilution (Serum) (N = 10)	Linearity of Dilution (Plasma) (N = 10)
Human sCD25 (IL-2Ra)	112%	121%
Human 4-1BB	129%	103%
Human sCD27	132%	127%
Human B7.2 (CD86)	125%	116%
Human Free Active TGF-β1*	84%	288%
Human CTLA-4*	110%	217%
Human PD-L1	94%	96%
Human PD-L2	136%	144%
Human PD-1	121%	102%
Human Tim-3	120%	64%
Human LAG-3	102%	99%
Human Galectin-9	120%	99%

\*Note: Linearity in plasma is poor for some anlaytes. Serum is the preferred sample type.

### Intra-Assay Precision

Two samples with different concentrations of target proteins were analyzed in one assay with 16 replicates for each sample. The intra-assay precision was calculated as below.

Analyte	Sample	Mean (pg/mL)	STDEV	%CV
Human sCD25 (IL-2Ra)	Sample 1	228.94	7.06	3%
Huiliali SCD25 (IL-2Ka)	Sample 2	876.36	38.43	4%
Human 4-1BB	Sample 1	238.94	7.02	3%
Human 4-188	Sample 2	791.97	30.03	4%
	Sample 1	913.79	31.47	3%
Human sCD27	Sample 2	3351.46	184.57	6%
	Sample 1	95.53	3.07	3%
Human B7.2 (CD86)	Sample 2	341.56	10.96	3%
Human Free Active	Sample 1	110.75	4.71	4%
TGF-β1	Sample 2	420.11	14.73	4%
	Sample 1	23.74	1.72	7%
Human CTLA-4	Sample 2	87.22	3.08	4%
Human PD-L1	Sample 1	46.04	1.69	4%
	Sample 2	169.99	9.08	5%
	Sample 1	26.79	0.99	4%
Human PD-L2	Sample 2	88.66	4.09	5%
Liveran DD 4	Sample 1	41.68	2.15	5%
Human PD-1	Sample 2	163.76	6.78	4%
Library Time 2	Sample 1	246.53	11.73	5%
Human Tim-3	Sample 2	924.69	25.40	3%
	Sample 1	931.82	39.84	4%
Human LAG-3	Sample 2	2772.19	130.44	5%
	Sample 1	2353.71	73.04	3%
Human Galectin-9	Sample 2	9149.64	500.32	5%

### Inter-Assay Precision

Two samples with different concentrations of target proteins were analyzed in four independent assays with 4 replicates for each sample. The interassay precision was calculated as below.

Analyte	Sample	Mean (pg/mL)	STDEV	%CV
Human sCD25	Sample 1	206.09	22.11	11%
(IL-2Ra)	Sample 2	806.51	90.62	11%
Human 4-1BB	Sample 1	202.62	21.16	10%
Human 4-188	Sample 2	702.13	80.66	11%
Human sCD27	Sample 1	823.65	70.24	9%
	Sample 2	3113.26	336.27	11%
Human B7.2	Sample 1	88.64	9.52	11%
(CD86)	Sample 2	332.57	41.13	12%
Human Free Ac-	Sample 1	111.11	2.54	2%
tive TGF-β1	Sample 2	440.17	34.96	8%
Human CTLA-4	Sample 1	18.40	2.03	11%
Human CTLA-4	Sample 2	73.84	10.37	14%
Human PD-L1	Sample 1	41.13	4.27	10%
Human PD-LI	Sample 2	147.51	19.19	13%
	Sample 1	21.22	2.02	10%
Human PD-L2	Sample 2	73.40	10.62	14%
Human PD-1	Sample 1	40.13	7.10	18%
Human PD-1	Sample 2	159.15	29.84	19%
Liveran Time 2	Sample 1	237.88	26.93	11%
Human Tim-3	Sample 2	978.56	128.70	13%
	Sample 1	608.35	94.81	16%
Human LAG-3	Sample 2	2120.69	414.74	20%
Human Galectin-9	Sample 1	2597.85	312.15	12%
	Sample 2	8976.95	1028.47	11%

### **Biological Samples**

#### Serum and Plasma

Normal human serum samples (n=17) were tested for endogenous levels using the LEGENDplex<sup>™</sup> HU Immune Checkpoint Panel 1. The concentrations measured are shown below.

Analyte	Range (pg/mL)	% of Detectable	Median (pg/mL)
Human sCD25 (IL-2Ra)	12.88 - 971.98	100%	563.73
Human 4-1BB	3.18 - 129.76	100%	17.95
Human sCD27	9219.00 - 73516.50	100%	28005.00
Human B7.2 (CD86)	110.47 - 34012	100%	204.72
Human Free Active TGF-β1	194.73 - 1172.14	100%	515.34
Human CTLA-4	0.78 - 142.00	29%	1.42
Human PD-L1	4.73 - 72.69	100%	10.42
Human PD-L2	874.50 - 11387.50	100%	6349.50
Human PD-1	2.17 - 59.46	88%	5.11
Human Tim-3	83.33 - 14449.23	100%	4082.19
Human LAG-3	46.08 - 573.70	53%	139.81
Human Galectin-9	24935.16 - 86232.93	100%	42183.04

Normal human plasma samples (n=20) were tested for endogenous levels using the LEGENDplex<sup>™</sup> HU Immune Checkpoint Panel 1. The concentrations measured are shown below.

Analyte	Range (pg/mL)	% of Detectable	Median (pg/mL)
Human sCD25 (IL-2Ra)	17.01 - 1386.22	100%	490.36
Human 4-1BB	4.43 - 474.41	100%	16.96
Human sCD27	23444.00 - 151672.50	100%	51377.25
Human B7.2 (CD86)	91.04 - 454.01	100%	240.31
Human Free Active TGF-β1	40.88 - 129.73	10%	85.31
Human CTLA-4	0.74 - 75.01	25%	6.89
Human PD-L1	5.60 - 297.40	100%	9.33
Human PD-L2	3763.00 - 32577.50	100%	9568.50
Human PD-1	2.22 - 222.47	75%	4.91
Human Tim-3	62.52 - 13411.09	100%	8053.20
Human LAG-3	48.90 - 2789.91	85%	92.14
Human Galectin-9	32855.23 - 86720.04	100%	52656.36

#### Cell Culture Supernatant

Human PBMCs (1 x 10<sup>6</sup> cells/mL) were cultured unstimulated and stimulated. The stimulation conditions were LPS (100 ng/mL); and LPS (100 ng/mL) and IFN-γ (100 ng/mL). Supernatants were collected after 42 hours of culturing and assayed with LEGENDplex<sup>™</sup> HU Immune Checkpoint Panel 1. The results (all in pg/mL) are summarized below.

Analyte	PBMC Control	PBMC + LPS	PBMC + LPS + IFN-γ
Human sCD25 (IL-2Ra)	22.51	463.53	2259.77
Human 4-1BB	ND	3.01	12.99
Human sCD27	5883.60	3308.44	4192.13
Human B7.2 (CD86)	3.03	5.48	14.53
Human Free Active TGF-β1	47.11	88.63	111.39
Human CTLA-4	ND	ND	ND
Human PD-L1	2.12	5.16	66.27
Human PD-L2	0.93	4.81	25.63
Human PD-1	1.23	1.03	1.27
Human Tim-3	18.79	38.31	236.22
Human LAG-3	ND	ND	818.76
Human Galectin-9	18848.91	6934.54	26862.41

Human PBMCs (1 x 10<sup>6</sup> cells/mL) were cultured unstimulated and stimulated. The stimulation condition was CD3 (1 µg/mL). Supernatants were collected after 4 days of culturing and assayed with LEGENDplex<sup>™</sup> HU Immune Checkpoint Panel 1. The results (all in pg/mL) are summarized below.

Analyte	PBMC Control	PBMC + CD3
Human sCD25 (IL-2Ra)	44.27	8446.75
Human 4-1BB	2.07	439.60
Human sCD27	5138.62	195607.29
Human B7.2 (CD86)	2.70	8.76
Human Free Active TGF-β1	10.05	79.50
Human CTLA-4	ND	1.75
Human PD-L1	1.80	218.31
Human PD-L2	2.02	8.82
Human PD-1	0.96	2.38
Human Tim-3	50.70	888.43
Human LAG-3	ND	20167.61
Human Galectin-9	5132.58	9881.30

# TROUBLESHOOTING

Problem	Possible Cause	Solution
Bead popula- tion shifting upward or downward dur- ing acquisition	The strong PE signal from high concentra- tion samples or stan- dards may spill over to classification Channel (e.g., FL3/FL4/APC) and mess up the bead separation.	Optimize instrument settings using Kit Setup Beads, and make appropriate com- pensation between channels.
	Vacuum pressure is insufficient or vacuum manifold does not seal properly.	Increase vacuum pressure such that 0.2 mL buffer can be suctioned in 3-5 seconds. Clean the vacuum manifold and make sure no debris on the manifold. Press down the plate on the manifold to make a good seal.
		Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
Filter plate will		If some wells are still clogged during wash- ing, try the following:
not vacuum or some wells clogged	Samples have insoluble particles or sample is too viscous (e.g., serum	1). Add buffer to all the wells, pipette up and down the clogged wells and vacuum again.
	and plasma samples)	2). Use a piece of clean wipe, wipe the un- der side of the clogged wells and vacuum again.
		3). Take a thin needle (e.g., insulin needle), while holding the plate upward, poke the little hole under each of the clogged wells and vacuum again. Do not poke too hard or too deep as it may damage the filter and cause leaking.
	Filter plate was used without pre-wet.	Pre-wet plate with wash buffer before run- ning the assay.

	i i i i i i i i i i i i i i i i i i i	
	Beads inappropriately prepared	Sonicate bead vials and vortex just prior to addition. Agitate mixed beads intermit- tently in reservoir while pipetting this into the plate.
Insufficient bead count or	Samples cause beads aggregation due to particulate matter or viscosity.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
slow reading	Beads were lost during washing for in-tube assay	Make sure beads are spun down by visu- ally check the pellet (beads are in light blue or blue color). Be very careful when removing supernatant during washing.
	Probe might be par- tially clogged.	Sample probe may need to be cleaned, or if needed, probe should be removed and sonicated.
	Vacuum pressure set too high	Adjust vacuum pressure such that 0.2 mL buffer can be suctioned in 3-5 seconds. Do not exceed 10" Hg of vacuum.
Plate leaked	Plate set directly on table or absorbent tow- els during incubations or reagent additions	Set plate on plate holder or raised edge so bottom of filter is not touching any surface.
	Liquid present on the under side of the plate after vacuum	After washing, press down plate firmly on a stack of clean paper towels to dry the underside of the plate.
	Pipette touching and damaged plate filter during additions.	Pipette to the side of wells.
High Back-	Background wells were contaminated	Avoid cross-well contamination by chang- ing tips between pipetting when perform- ing the assay using a multichannel pipette.
ground	Insufficient washes	The background may be due to non- specific binding of SA-PE. Increase number of washes.
Debris (FSC/ SSC) during sample acquisi- tion	Debris or platelet may exist in sample solu- tion.	Centrifuge samples before analyzing samples. Remove platelet as much as possible.

	1	
	Beads aggregation	Sonicate and vortex the Beads prior to use.
Variation be-	Multichannel pipette may not be calibrated or inconsistent pipet- ting	Calibrate Pipette. Ensure good pipetting practice. Prime pipette before use may help.
tween duplicate samples	Plate washing was not uniform	Make sure all reagents are vacuumed out completely in all wash steps.
	Samples may contain particulate matters.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
Low or poor standard curve	The standard was in- correctly reconstituted, stored or diluted	Follow the protocol to reconstitute, store and dilute standard. Double check your calculation.
signal	Wrong or short incuba- tion time	Ensure the time of all incubations was appropriate.
Signals too high, standard curves satu-	PMT value for FL2/PE set too high	Make sure the PMT setting for the re- porter channel is appropriate
rated	Plate incubation time was too long	Use shorter incubation time.
	Samples contain no or below detectable levels of analyte	Make sure the experiment to generate the samples worked. Use proper positive controls.
Sample read- ings are out of range	Samples concentrations higher than highest standard point.	Dilute samples and analyze again.
	Standard curve was saturated at higher end of curve.	Make sure the PMT setting for the re- porter channel is appropriate. Use shorter incubation time if incubation time was too long
Missed beads populations during reading, or distribution	Sample may cause some beads to ag- gregate.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
is unequal	Beads populations are not mixed properly	Make sure all bead populations are mixed. and in similar numbers.

PLATE MAP (for in-plate assay)

	1	2	3	4	5	9	7	8	6	10	11	12
۷	CO	C4	Sample1	Sample5	Sample 9	Sample 13	Sample 17	Sample 21	Sample 25	Sample 29	Sample 33	Sample 37
ß	CO	C4	Sample1	Sample5	Sample 9	Sample 13	Sample 17	Sample 21	Sample 25	Sample 29	Sample 33	Sample 37
U	C1	S	Sample2	Sample6	Sample 10	Sample 14	Sample 18	Sample 22	Sample 26	Sample 30	Sample 34	Sample 38
۵	C1	S	Sample2	Sample6	Sample 10	Sample 14	Sample 18	Sample 22	Sample 26	Sample 30	Sample 34	Sample 38
ш	C2	CG	Sample3	Sample7	Sample 11	Sample 15	Sample 19	Sample 23	Sample 27	Sample 31	Sample 35	Sample 39
Ľ	3	90	Sample3	Sample 7	Sample 11	Sample 15	Sample 19	Sample 23	Sample 27	Sample 31	Sample 35	Sample 39
U	ទ	C7	Sample4	Sample8	Sample 12	Sample 16	Sample 20	Sample 24	Sample 28	Sample 32	Sample 36	Sample 40
I	ព	C	Sample4	Sample8	Sample 12	Sample 16	Sample 20	Sample 24	Sample 28	Sample 32	Sample 36	Sample 40



LEGENDplex<sup>™</sup> Kits are manufactured by **BioLegend** 9727 Pacific Heights Blvd. San Diego, CA 92121 Tel: 1.858.768.5800 Tel: US & Canada Toll-Free: 1.877.Bio-Legend (1.877.246.5343) Fax: 1.877.455.9587 Email: info@biolegend.com biolegend.com

For a complete list of world-wide BioLegend offices and distributors, please visit our website at: biolegend.com

750000505\_R01